

<b>PRODUCT INFORMATION</b>
<b>STRING BED CARE &amp; MAINTENANCE</b>
<b>READ THIS DOCUMENT AND ALL OTHER ACCOMPANYING PRODUCT DOCUMENTATION THOROUGHLY BEFORE INSTALLING, USING OR PERMITTING USE OF THIS EQUIPMENT. REQUIRE ALL PERSONS INTENDING TO USE THIS EQUIPMENT, AS WELL AS THOSE INSTRUCTING, ASSISTING OR COACHING OTHERS IN THE USE OF THIS PRODUCT, TO READ THIS DOCUMENT THOROUGHLY BEFORE AUTHORIZING THEM TO ENGAGE IN THOSE OR RELATED ACTIVITIES.</b>

String beds provide great lift because they weigh less and produce far less air resistance than solid or web beds, but are also vulnerable to wear and damage. To achieve maximum string bed life, your bed must be properly and regularly repainted.

**NOTE::** PAINT—NOT STRING—IS YOUR BED'S WEAR SURFACE. PROTECTED PROPERLY WITH PAINT, YOUR BED SHOULD PROVIDE YOU WITH GOOD SERVICE FOR MANY YEARS.

If your trampoline is always kept indoors and not used heavily, you may be able to get by repainting it once every 6-12 months.

Otherwise—especially if your trampoline is permanently located outdoors—it should be repainted every 3 or 4 months. In addition to protecting your bed from wear, paint also minimizes damage from both ultraviolet solar rays and rain.

At very least, bed should always be painted when dark undercoat begins to show through.

High quality latex paint, available from most local paint or home improvement stores, is recommended. (Latex paint is not made from natural rubber latex and thus does not present an allergy hazard.) This type of paint is heavy so do not use more than needed for full coverage (latex paint may be thinned with water if done according to manufacturer's instructions).

Start by installing bed as you would for regular use. Then apply paint to both top and bottom of bed with a roller applicator. Lightly tapping the bed with a piece of hose, a length of broomstick or some similar smooth object will remove excess paint from the weave. Allow 12 to 24 hours for paint to completely dry.

Use same type paint to do cross and box. Simply mask off lines with 2" tape.



**IMPORTANT CONSUMER PRODUCT HAZARD WARNING — PLEASE READ!**

A possibility of serious injury, including paralysis or death, is inherent in any activity involving motion or height. Equipment with which this notice is included is intended for use only by properly trained, qualified persons under supervised conditions. Use without proper supervision is dangerous and should not be undertaken or permitted. Know your limitations as well as the limitations of your equipment. Consult a qualified instructor before attempting any new activity or skill. This equipment must be used with proper mats, spotting equipment and qualified spotters for each activity or skill. Use this equipment only for its intended purpose. Do not modify equipment in any way. Inspect each component for damage, loose fittings or signs of wear before each use. Do not use if you have any concern as to the condition of this equipment. Test unit for stability prior to each use. Do not use if you have any concern about the stability, condition or suitability of this equipment. Inspect warning labels and replace when marred or damaged. Before each subsequent use, re-check equipment stability and settings.