


G-263 Heavy Duty Cable Tensioners



INSTALLATION INSTRUCTIONS

1. **WARNING!** Failure to follow these instructions could cause injury to users of the gymnastic equipment this tensioner is used with.
2. Remove the two 1/4" bolts and the bearings.
3. Unscrew the "T"-handle all the way. Sandwich cables between plates.
4. Replace the bearings and 1/4" bolts. Tighten the elastic stop nuts on the bolts all the way and then back-off slightly to allow bearings and cables to move freely.
5. Tighten the "T"-handle to brake unit. Unloosen the "T"-handle to allow positioning as necessary.
6. "U" shape handle of the tightener unit goes in the "up" position. Coach or larger person can then pull it upward to tighten the cables as needed. Small students can move the tensioner easiest by holding the outwardly extended plastic handles to position as needed. Refer to above illustration.