

Beam Leg Mounting Hardware

For Models BB-108, BB-108S, G-108, G-108S, G-111, G-113 and G-114

PRODUCT INFORMATION

READ THIS DOCUMENT AND ALL OTHER ACCOMPANYING PRODUCT DOCUMENTATION THOROUGHLY BEFORE INSTALLING, USING OR PERMITTING USE OF THIS EQUIPMENT. REQUIRE ALL PERSONS INTENDING TO USE THIS EQUIPMENT, AS WELL AS THOSE INSTRUCTING, ASSISTING OR COACHING OTHERS IN THE USE OF THIS PRODUCT, TO READ THIS DOCUMENT THOROUGHLY BEFORE AUTHORIZING THEM TO ENGAGE IN THOSE OR RELATED ACTIVITIES.

This packet contains:

- 8 each 3/8" zinc plated steel washers
- 8 each 3/8" x 2" zinc plated lag screws

Please use these bolts **ONLY** for wood beams.

IMPORTANT! Failure to do so could cause a beam leg and/or beam to collapse.

If your beam is not predrilled to the correct hole pattern use a 19/64" drill bit and drill into the beam 2 to 2-1/4" deep. Use legs as a template.

DO NOT OVER TIGHTEN! Periodically check bolts for tightness. An uneven or wobbly beam can often be fixed by tightening (or loosening) bolts diagonally across from each other on opposite legs.

Call manufacturer if you have any questions or concerns.



8 each 3/8" x 2" lag screws



8 each 3/8" flat washers

⚠ IMPORTANT CONSUMER PRODUCT HAZARD WARNING — PLEASE READ!

A possibility of serious injury, including paralysis or death, is inherent in any activity involving motion or height. Equipment with which this notice is included is intended for use only by properly trained, qualified persons under supervised conditions. Use without proper supervision is dangerous and should not be undertaken or permitted. Know your limitations as well as the limitations of your equipment. Consult a qualified instructor before attempting any new activity or skill. This equipment must be used with proper mats, spotting equipment and qualified spotters for each activity or skill. Use this equipment only for its intended purpose. Do not modify equipment in any way. Inspect each component for damage, loose fittings or signs of wear before each use. Do not use if you have any concern as to the condition of this equipment. Test unit for stability prior to each use. Do not use if you have any concern about the stability, condition or suitability of this equipment. Inspect warning labels and replace when marred or damaged. Before each subsequent use, re-check equipment stability and settings.